



# SELF SERVICE VEHICLE CLEANING SYSTEMS AIR & WATER TOWER



**Our Air and Water Tower is a self-contained, stainless steel unit with an integrated air compressor rated for HGV use and a water supply to top up windscreen washer reservoirs**

The equipment features user-adjustable pressure settings with a clear pressure display. Both air and water supplies are dispensed via a retractable, 10m hose.

**PLEASE NOTE:**

This machine requires 230v electric supply on a 16amp, C-Rated breaker.

**AIR & WATER TOWER**

**USER-ADJUSTABLE PRESSURE SETTING**

**PRESSURE SETTING DIGITAL DISPLAY IN BAR/ PSI**

**STAINLESS STEEL CABINET**

**HGV FREE VEND**

**CONNECTOR ARM**

**KICK PLATE**

**10M AIR & WATER HOSES**



# SELF SERVICE VEHICLE CLEANING SYSTEMS AIR & WATER TOWER

## INSTALLATION SPECIFICATION:

### ELECTRICAL REQUIREMENTS:


- Constant, 24 hour, 16 Amp 230/240v AC Single Phase Supply
- Voltage drop must be calculated to ensure the above conditions are met
- All Supply Cables must be protected by RCD or RCBO Tripping Current 30mA Separate 6mm Earth Conductor (CPC) Recommended
- Minimum of 1 Metre cable protruding above ground at the service point

### WATER REQUIREMENTS:

- Constant 4 litres/minute
- Minimum of 1 Metre of 20mm insulated pipe protruding above ground at the service point

### BASE SPECIFICATION:

- **700mm x 660mm**
- **Base Depth 150mm**
- **Securely Keyed In**



DENOTES WATER & ELECTRICAL SERVICES

### CABINET SIZE:

Height 1200mm / Width 560mm / Depth 520mm